Instruction of RF7121



Figure 1 button ofremote**Item**

1.1 Sleeping button 1

Click the button to switch to the Sleep mode.

1.2 Child Lock button 2

Click and hold Child Lock button for 5s until backlight flashes, then the lock/unlock is complete.

1.3 Reading button 3

Click the button to activate the Reading Mode.

1.4 Zero-Gravity button 4

Click the button to run Zero-Gravity Mode.

1.5 TV button 5

Click the button to switch to the TV mode.

1.6 M button 6

Click the button to move to the M memory position.

1.7 Lumbar Elevate button 7

Click the button to activate the Lumbar Elevate mode.

1.8 Flat button 8

Click this button, the bed goes flat.

1.9 Lumbar Descend button 9

Click the button to activate the Lumbar Descend mode.

1.10 Head up button 10

Press and hold the button to extend the head driver, and release to stop.

1.11 Head+Foot up button 11

Press and hold the button to extend the head and foot drivers, and release to stop.

1.12 Foot up button 12

Press and hold the button to extend the foot driver, and release to stop.

1.13 Head down button 13

Press and hold the button to retract the head driver, and release to stop.

1.14 Head+Foot down button 14

Press and hold the button to retract the head and foot drivers, and release to stop.

1.15 Foot down button 15

Press and hold the button to retract the foot driver, and release to stop.

1.16 Massage ON/OFF button 16

Click the button to toggle the massage motor on or off. If the massage motor is on, it will turn off; if it is off, it will turn on.

1.17 Under Bed Light button 17

click this button to turn on/off under bed lighting.

1.18 Timer button 18

Click the button to toggle the massage time between 10min, 20min, and 30min. When the massage time is set to 0, the massage will turn off. The button will not function when the massage is turned off.

1.19 Massage Head button 19

Click the button to toggle the intensity of the head massage motor. The massage intensity will cycle through levels 1-2-3-0.

1.20 Massage mode button 20

Click the button to activate the Massage mode.

1.21 Massage Foot button 21

Click the button to toggle the intensity of the foot massage motor. The massage intensity will cycle through levels 1-2-3-0.

FCC：

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

ISED RSS Warning:

This device complies with Innovation,Science and Economic Development Canada licenceexempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.
Le présent appareil est conforme aux CNR d'ISED applicables aux appareils radioexempts de licence.
L'exploitation est autorisée aux deux conditions suivantes:

(1) l'appareil ne doit pas produire de brouillage, et

(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.