

# [CE-LINK QI2 Wireless Charger User Manual](#)

## [Manualsum](#), simplified manuals

### Table of Contents

- [CE-LINK QI2 Wireless Charger User Manual](#)
  - [Description](#)
  - [Specification](#)
  - [Operation](#)
    - [Radiation Exposure Statement](#)

# CE-LINK QI2 Wireless Charger User Manual

CE-LINK QI2 Wireless Charger User Manual

MPP15-1TCNB-J Wireless Charger User Manual

[A4X-MPP15-1TCNB-J](#)

## Description

This product is a one-in-one wireless charging bracket, the input end is a TYPE-C mother-socket interface, the input voltage is 5V/9V, and the output Support Qi standard BPP 5W and MPP 15W. Magnetic wireless charge support iPhone 12 series, iPhone 13 series, iPhone 14 series, iPhone 15 series wireless charging, The product uses self-developed CE223 QI2 module.

## Specification

<b>Model</b>	MPP15-1TCNB-J
<b>Input</b>	S5V/3A, 9V/2.22A
<b>Output</b>	SW/7.5W/15W
<b>Wireless Charging Frequency</b>	110.5~384kHz
<b>Operation Temperature Range</b>	0~40°C

[Manualsum](#)

# Operation

**3.1.** Connect the wireless charger to the power adapter, and connect the power adapter to the power supply.

**3.2.** Place your device (which supports wireless charging) on the wireless charger.

**3.3.** Please take out the device after it is fully charged.

## **Radiation Exposure Statement**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.