# CODi Magnetic Wireless Charging Power Bank User Manual 2A7KXPB005-CW

#### **Manualsum**, simplified manuals

#### Table of Contents

- Magnetic Wireless Power Bank User Manual
  - Product Specifications
  - Charging Instructions
  - LED Indicators
  - Safety Considerations:

## Magnetic Wireless Power Bank User Manual

(2A7KXPB005-CW)



Thank you for purchasing our Wireless Charging Power Bank. For optimum performance and safety of using this product, please read these instructions carefully before operating the product. Please keep this manual for future reference.

#### **Product Specifications**

Capacity 5000mAh

Battery Cell Li-Po 676074

Material Aluminum

**Input** 5V/2.4A 12W, 9V/2A 18W


Output USB-C: 5V/3A 15W, 9/2.22A 19.98W,

12V/1.67A 20W Max

Circulation >300 times
Working Temp 14F-112F
Storage Temp 68F-77F
LED Indicator Yes

**Dimensions** 3.9in x 2.5in x .4in


Weight 0.26lbs



**Power On/Off:** Press the power on/off button, the LED indicator light will illuminate.

**LED Display:** The LED indicator light will flash when charging. This device will automatically power off when not in use.

### **Charging Instructions**



#### **LED Indicators**

Indicator	Battery level
00000	0% - 25%
●◎○○○	25% - 50%
	50% - 75%
	> 75% < 100%
	100%

Fifth indicator light will show a solid blue when wirelessly charging

Fifth indicator light will flash blue when it can not connect and charge to object wirelessly

First light will show a solid green when fast charging the power bank

#### **Safety Considerations:**

- 1. DO NOT place power bank in or near fire
- 2. DO NOT disassemble, open, crush, bend, deform, puncture, shred or submerge the power bank
- 3. DO NOT attempt to dry this device with any appliance or heat sources such as a hairdryer or microwave oven
- 4. Children should be supervised when using this device
- 5. Avoid dropping power bank