

DGL Wireless Magnetic Speaker User Manual

Manualsum, simplified manuals

Table of Contents



- [DGL Wireless Magnetic Speaker User Manual](#)
 - [Description](#)
 - [Product Specification](#)
 - [Contents Inside](#)
 - [Power On/Off](#)
 - [Bluetooth connect](#)
 - [Hands-free call](#)
 - [Pause/Play Music](#)
 - [Volumen](#)
 - [TWS connection](#)
 - [Clear Connection](#)
 - [Save Power](#)
 - [Charging](#)


DGL Wireless Magnetic Speaker User Manual

DGL Wireless Magnetic Speaker User Manual

([2AANZMSMS](#))

Description





Product Specification

Bluetooth Version	V5.3
Bluetooth Frequency	2402MHz - 2480MHz
Input	DC 5V / 350mA
Output	3.7V, 700mAh
Distortion	<1%
Playing Time	12 hours
Size	Diameter 60 * 36 mm
Frequency Range	80Hz - 20KHz
Support	TWS Connection
Features	Compact size with big sound
FCC ID	2AANZMSMS
BT ID	DO59694

Contents Inside

1. wireless magnetic speaker
2. carrying pouch
3. metal ring
4. USB-C charging cable
5. user manual



Power On/Off

To power on: press and hold © for two seconds.

To power off: press and hold @) for two seconds.

Bluetooth connect

1. The working indicator will flash in blue after the speaker is powered on.
2. Turn on the Bluetooth on your phone and search for the device; select "BRK-MSMS" to connect.
3. After connecting, the working indicator will keep lighting in blue.
4. The speaker will automatically reconnect your phone the next time it is powered on, on the condition that its Bluetooth is still on.

Hands-free call

Short press "I" to answer an incoming call, press the same again to end it.

Pause/Play Music

Short press "I" to pause music while playing. Press "I" again to resume play.

Volumen

Sync the recent media volume on your phone; the default volume is 50% after each power on.

TWS connection

1. After both speakers are powered on, connect one to your phone's Bluetooth® and keep the other one(s) from connecting to any other device.
2. Double press the [1] button on both speakers and the working indicator will flash blue and white alternately.

3. After the pairing is successful, the left channel speaker working indicator keeps lighting in blue, and the right channel speaker working indicator lights white.
4. Each speaker will automatically reconnect in TWS mode the next time they power on.

Clear Connection

1. Triple press the [1] button to clear and disconnect TWS and Bluetooth®.
2. The speaker enters the waiting pairing state, and the working indicator flashes blue.

Save Power

The speaker will power off automatically to save power if it stops working for more than 20 min.

Charging

1. When the speaker battery runs low, it automatically reduces the volume to warn you it has entered a power-saving state.
2. In this case, please charge the speaker immediately. While charging, the charging indicator will light orange.
3. Once charging is completed, the charging indicator becomes green.

Note: If not used for a long time, please charge the speaker at least once every three months to extend the battery life.

DGL Wireless Magnetic Speaker User Manual