

# [Dongguan Weimei Clothing and Apparel Find My Tracker User Manual](#)

## [Manualsum](#), simplified manuals

### Table of Contents

- [Dongguan Weimei Clothing and Apparel Find My Tracker User Manual](#)
  - [DS Holder Operating Instructions](#)
    - [How to set up the locator](#)
  - [How to remove the locator](#)
  - [How to charge the locator](#)
  - [Safe electrical disposal](#)
  - [How to restoring the factory setting](#)
  - [Warning](#)
  - [Disclaimer](#)
  - [Limited warranty](#)
  - [Leather Care Tips](#)

## **Dongguan Weimei Clothing and Apparel Find My Tracker User Manual**

Dongguan Weimei Clothing and Apparel Find My Tracker User Manual

FCC id: [2BHWU-KP01](#)

### **DS Holder Operating Instructions**

**\*To use the Apple Find My app to locate this item, the latest version iOS, iPadOS, or macOS is recommended.**

#### **How to set up the locator**


First make sure WiFi and Bluetooth are turned on

[Manualsum](#)




Make the DS Lable discovered following the steps:

1. Press the power button 3seconds,after the ringtonerings and the Controlling light blinks in white, the DS Holder is ready.




2. Turn on the Apple "Find My" App, Click "Add Item" | then click "Other Supported Item" .




3. Bring the DS Lable close to iPhone, identify the locator, then click "Connect"

4. Customize the "name" and "emoji" of the DS Lable, then the setting is complete.




## How to remove the locator

1. Turn on the Apple "Find My" App, Click "Items" , then Swipe left on the item you want to remove.




2. After removal, DS Lable will sound a tone and a white light will flash.



## How to charge the locator

\*DS Holder supports wireless charging function, you can use wireless charger to charge it.

1. Align the battery coil position with the wireless charger.
2. When the DS Holder starts charging, it will sound a bell and light a red light.
3. When the DS Holder is fully charged, it lights green, then please remove it from the charger.



Side B

## Safe electrical disposal

The earth is our common home and DISIDUW attaches great importance to protecting the cleanliness of the environment and avoiding its pollution.

When your device reaches the end of their useful life, please dispose of at your locale-wastecenter to be recycled and properly discarded.

## How to restoring the factory setting

Click the power button four times, and then press the power button for some seconds long; When the ringtone sounds, the light flashes in white quickly.

That is completed.

## Warning

1. This product is not a toy or edible.
2. Obstacles or large metal objects can interfere with the Bluetooth signal.
3. This product has a built-in lithium battery. Please do not put this product directly on fire or any place near heat or fire. Otherwise, the product may be damaged or malfunctioned, or even be dangerous.

## **Disclaimer**

This is neither an anti-theft nor an anti-lost device.

This device provides the last detected location.

## **Limited warranty**

DISIDUW offers a one-year limited warranty against product defects, effective from the time of delivery. Product defects do not include those resulting from accidents, product modification, or failure to follow instructions for use.

## **Leather Care Tips**

1. Keep dry and avoid damp environments to prevent leather mold.
2. Avoid direct sunlight to prevent aging, discoloration, and cracking.
3. Avoid contact with alcohol, vinegar, lemon juice, and detergents to prevent leather corrosion.
4. Use a damp towel or soft cloth to clean surface stains, then air dry in a ventilated area.