E-filliate Incorporated 3in1 Foldable Wireless Charger User Manual

Manualsum, simplified manuals

Table of Contents


- E-filliate Incorporated 3in1 Foldable Wireless Charger User Manual
 - Product Introduction
 - Method of Operation
 - Specification
 - Compatible Model
 - 0&A
 - Safety Notice
 - Package List

E-filliate Incorporated 3in1 Foldable Wireless Charger User Manual

E-filliate Incorporated 3in1 Foldable Wireless Charger User Manual

FCC id: 2ADH6-1410020


3-in-1 Foldable Wireless Charger




Please read the instructions carefully before using

Product Introduction

This product is a 3in1 multi-functional wireless charging station, which supports fast charging for phone, iWatch and AirPods at the same time, it provides high efficiency and stable wireless charging or you.



Method of Operation



- 1. Use charging cable provided in the package to connect with the wireless charger, plug the adapter in the power supply.
- 2. Place the devices to be charged in the corresponding charging area, then it will start charging.



These 3 LED indicator lights will change according to the charging status of phone, Watch and AirPods.

	Phones	iWatch	AirPods
Power On	Green On for 3 Seconds	Green On for 3 Seconds	Green On for 3 Seconds
Standby	Turn off	Turn off	Turn off
Charging	Green for 30s then off	Green for 30s then off	Green for 30s then off
Completed	Turn off	Turn off	Turn off
FOD & Error	Green Flash	None	Green Flash

	Phones	iWatch	AirPods
Power On	Green On for 3 Seconds	Green On for 3 Seconds	Green On for 3 Seconds
Standby	Turn off	Turn off	Turn off
Charging	Green for 30s then off	Green for 30s then off	Green for 30s then off
Completed	Turn off	Turn off	Turn off
FOD & Error	Green Flash	None	Green Flash

Specification

Model Number: 17Air
 Input: 5V==3A/9V==3A

• **Output:** 5W/7.5W/10W/15W Max(Phone)

Output: 3W(AirPods)Input Interface: Type-C

Transmission Distance(for phone): ≤ 4mm
 Product Size: 150*121.5*17mm (Folded)
 Product Name: Foldable Wireless Charger

Compatible Model

1. Phone

Phone with wireless charging function and compatible with charging protocol.

2. iWatch

Apple Watch 9/8/7/6/5/4/3/2/SE/Ultra/Ultra 2

3. Airpods

AirPods Charging: for AirPods 2/3/Pro/Pro2 (can work with A2700, A2566, A2190, A1938 AirPods case)



Note: Does not support A2897, A1602 AirPods case

Q&A

Q What should doi the charger doesn'c work o charge devices intermittently?

A: Please check the following steps:

- 1. Please make sure your devices have wireless charging function and can be charged wirelessly
- 2. Please use the adapter and cable provided in the package
- 3. please check if the charging indicator light is on, if not please unplug and reinsert the adapter and case.
- 4. Please use other 18W adapter and charging cable to check if the adapter and cable are damaged.
- 5. Please make sure that the thickness of the phone case is 4mm (if there is a case) and there are no any metal, pop rings, cred cards or magnetic interference charges.
- 6. Please align the coil of your devices with the charging center.
- 7. Update your device to the latest system and restart the device

Q: What should I do the charging is slow?

A: Please check the following steps:

- 1. Please make sure to use the 18W adapter and cable provided in the package.
- 2. Charging efficiency depends on the receving power of your devices and it is not recommended to keep the APP running during slow charging.

Q: Whatsnould I do if the charger heats up during charging?

A: Please check the following steps:

1. It is normal for the receiving coil or transmitter board to generate heat during wireless charging. If the charger is to hot please take your

<u>Manualsum</u>

- phone off from charger to wait the charger to cool down and charge again.
- 2. It is recommended to avoid using the charger in high temperature and sun exposure environments as possible.

Safety Notice

- 1. Do not disassemble or throw the product into ffire or water to avoid short circuit.
- 2. Do not use wireless charger in extremely hot, humid or corrosive environment
- 3. Make sure there are no any metal, pop rings, credit cards or magnetic interference charges.
- 4. Keep out of reach of children and pets.
- 5. If the charging station overheats and stops charging during use, please remove the charging device and try charging after cooling down.
- 6. Avoid dropping the product from high place.

Package List

Package List

- 1. Foldable wireless charger *1
- 2. Type-C charging cable *1
- 3. User Manual *1