

Bamboo solar Bluetooth Speaker User Manual

Manualsum, simplified manuals

Table of Contents


- [Bamboo solar Bluetooth Speaker User Manual](#)
 - [Overview](#)
 - [Specifications](#)
 - [Charging the speaker:](#)
 - [Connection to Wireless device:](#)
 - [Playing music:](#)
 - [Safety instructions:](#)

Bamboo solar Bluetooth Speaker User Manual

Bamboo solar Bluetooth Speaker User Manual

FCC id: [2BH7M-LKBTS373](#)

Overview



1. Solar Panel

[Manualsum](#)

2. Type C input port
3. Light Indicator
4. Switch button ON/OFF

Specifications

- **Wireless Version:** V5.1
- **Power Output:** 3W
- **Power Supply:** DCSV-1/2A
- **Battery capacity:** 300mAh
- **Input solar:** approx. 100mAh/ hour
- **Transmission Range:** <10m
- **Input Sensitivity:** ≥ 80 dB
- **Charging time:** via cable about 3-4h; via sunlight about 6-8h
- **Playing time:** approx. 3h

Charging the speaker:

1. Connect the provided Type C charging cable to speaker Type C port;
2. Insert the other end to the USB port to a suitable power source (recommended wall charger with at least 5W output power)
3. During charging process red LED light will be visible; the LED light will switch off after charging process is finished
4. Or alternatively put speaker under the sunlight to be charged via solar panel. Green LED light is visible during solar charging process

Connection to Wireless device:

- Follow the operating instructions of your Wireless device for pairing with the speaker.
- Normally this is done by going to the * Wireless", "Set Up® or *Connect' menu and selecting the option to search for Wireless devices.
- Press the speaker button to power on
- When pairing, look for *LK-BTS-373" on your Wireless device and select this for pairing.
- When pairing is successful, you can hear some voice indicator.
- When the speaker is used again - second time or next times - newer devices should reconnect automatically. If connection fails, please follow the above steps in these instructions

Playing music:

1. Press the speaker button to "Power on/ off/ Play music/ Pause music
2. You can also use your device to select "Previous track/ Volume Down" or/and "Next track/ Volume Up'

Safety instructions:

- Do not drop or bump this product.
- Do not disassemble, do not repair the speaker yourself.
- Please use the power charger with rated voltage for the speaker.
- Please disconnect the USB-C cable after charging finish
- Charge the speaker battery atleast once in 3 months' time to maintain proper battery life
- Do not dispose of the device with household waste. For disposal it should be transferred to a specialized disposal company