HAFF01 Bluetooth Speaker User Manual

Manualsum, simplified manuals

Table of Contents

- HAFF01 Bluetooth Speaker User Manual
 - Packing List
 - Button/Interface Introduction
 - Button function description
 - Function usage
 - Bluetooth connection
 - TF card/U-disk/Aux in mode
 - Function usage
 - <u>TWS</u>
 - Specifications
 - Certificate and Warranty Card
 - Kindly reminder

HAFF01 Bluetooth Speaker User Manual

HAFF01 Bluetooth Speaker User Manual

Haoyue Supply Chain HAFF01 Bluetooth Speaker User Manual

FCC id: 2BKB5-HAFF01




Bluetooth Speaker User's Manual Ver 1.0

Welcome to purchase our speaker, in order to let you use this product better, please read the manual carefully.

<u>Manualsum</u>

* Due to the iterative upgrading of the product, there may be some changes in the description and packaging. Please refer tcetreal object!


Packing List



Bluetooth Speaker


Manualsum





3.5 Audio Cable


User's Manual



Type -c Charging Cable

<u>Manualsum</u>

Button/Interface Introduction



- 1. On, Off/Mode switching/Indicator TWS connection
- 2. EQ switch / Play pause /Answer&hang up the call/ Disconnect Bluetooth
- 3. Volume + / Next track
- 4. Volume /previous track
- 5. 3.5 AUX audio input
- 6. Type-C charging port
- 7. Reset
- 8. TF card
- 9. U disk

Button function description

Button	Operation	Function Description	n
	Short press	Mode switching: Bluetooth / Au disk play	лх / TF / U
	Long press	Long press for 3 seconds to turn on / off	
	Double click	Initiate TWS pairing. After pairing is successful, you can double-click to disconnect TWS	
	Short press	Pause / playing	<u>Manualsum</u>

	Davible eliels	Switch EQ mode	
	Double click	Long press for 3 seconds to disconnect	
F	Long press	the Bluetooth connection	
	Incoming call short press	Short press to answer the call when calling, and short press to end the call during the call	
\wedge	Short press	Volume up	
	Long press	Next track	
N /7	Short press	Volume down	
\vee	Long press	Previous track	
≪ +≫	Press for 2 seconds at the same time	Light on/off	

Function usage

Bluetooth connection

Long press the power button for 3 seconds to start the speaker. The machine enters the Bluetooth mode. The blue light of the power button icon flashes to enter the pairing state. The mobile phone searches for the Bluetooth name "HAFF01 ' and clicks to connect.

TF card/U-disk/Aux in mode

- Insert the TF card into the card slot or insert the U-disk to the U-disk slot, the bluetooth speaker automatically enter TF card or U-disk mode to play music. (The Max capacity is 32G for TF card or U-diskit can be recognized by the speaker)
- Connect any audio device with a 3.5mm jack and connect it to the aux audio cable to play.

Function usage

TWS

1. Turn on the two speakers (* if there is a Bluetooth device connected, the Bluetooth connection must be disconnected first)

Double click the " " of one of the speakers to enter TWS pairing, and there is a prompt tone; After successful pairing, the blue



of the main machine flashes quickly, and the



- 3. At this time, open the Bluetooth device, search for the Bluetooth name * HAFF01 * , and click Connect. Play music and enjoy wireless stereo sound.
- 4.



to disconnect TWS pairing when TWS is

Double click connected.

light of the

5. After the TWS connection is successful, the machine will automatically enter the TWS interconnection (under the state of non active disconnection of TWS) after each startup

Specifications

Bluetooth version	V5.0	Charging voltage	5V2A
Bluetooth transmission distance	≥10m	Charging time	4-5H
Power	2*20W	Frequency response	60hz—18Khz
Capacity of battery	2600mAh*2	Waterproof level	IPX7
Local decoding	Support MP3/FLAC/ APE/WMA	Product size	105*105*130mm

2.

Certificate and Warranty Card

Certificate	Warranty Card	
Product name	User's name	
Model	Date of purchase	
Color	Contact information	
Production Date	Warranty record 1	
Executive standard	Warranty record 2	
Test result	Remark	

Kindly reminder

- Please check the charger specifications before charging, do not use fast charging or high voltage chargers to charge the speaker. For hearing health, please do not use it at maximum volume for a long time.
- Do not use it near a fire source or in a high temperature environment to avoid permanent damage to the speaker.
- Please use it strictly in accordance with the instructions, and do not modify or disassemble the product without permission.
- Do not drop, impact, knock, squeeze or other behaviors that seriously affect the product structure to avoid damage to the strength and reliability of the product.
- If you encounter high temperature, deformation, corrosion and other abnormalities during use, please stop using it immediately and contact the merchant for proper disposal.

Executive standard ©: GB8998 -2011;GB/T13837 - 2012;GB17625.1 - 2012