

[MERKURY Innovations Touch Lamp with Wireless Speaker User Manual](#)

[Manualsum](#), simplified manuals

Table of Contents

- [MERKURY Innovations Touch Lamp with Wireless Speaker User Manual](#)
 - [ON-BOARD CONTROLS \(TOP\)](#)
 - [SPECIFICATIONS](#)
 - [Product Specifications:](#)
 - [Bluetooth® Information:](#)
 - [Technical specifications:](#)
 - [INSTRUCTIONS:](#)
 - [Charging the Battery:](#)
 - [Using the Lamp:](#)
 - [Connecting to a Bluetooth Device:](#)
 - [TROUBLESHOOTING](#)
 - [TECHNICAL SUPPORT](#)

MERKURY Innovations Touch Lamp with Wireless Speaker User Manual

MERKURY Innovations Touch Lamp with Wireless Speaker User Manual

Ningbo Beslight Imp.&Exp. Touch Lamp with Wireless Speaker User Manual

MERKURY BT133 User Manual


FCC id: [2BHJU203546](#)

MERKURY
INNOVATIONS



 **Bluetooth®**

ON-BOARD CONTROLS (TOP)



SPECIFICATIONS

Product Specifications:

- Dimensions: 4.1" x 4.1" x 14" (Height x Width x Depth)
- Weight: 1.12lb
- Input Voltage: 5V 1A
- Output Voltage: 3.7V
- Output Watts: 3W
- Indoor use only

Bluetooth® Information:

BT Version: V5.4

Bluetooth® Range: 10m

Technical specifications:

- Sound: Mono
- Bluetooth IC Model and Version: ABS365A / V5.4
- Bluetooth Pairing Name: MERKURY BT133
- Bluetooth Speaker Output: SW
- Frequency Response: 20Hz-20kHz
- Distortion: <10% (Tested with iPhone at max volume)
- SNR: 285dB (Tested with iPhone at max volume)
- Charging Current: Max 1000mA
- Battery Capacity: 2000mAh
- Bluetooth Range: 10 meters
- BQB Certification for BT IC: Yes
- Battery with PCM: Yes
- Play Time: 3.5-4 hours
- Charging Time: 3-4 hours
- Charging Port Type: Type C
- Number of Channels: 1
- Speaker Size: \varnothing 40mm H=21mm

INSTRUCTIONS:

Charging the Battery:

- Use the provided USB cable to fully charge the desk lamp.
- Place the lamp on a stable surface.
- Touch the power button on top to turn on the lamp.

Using the Lamp:

- Touch the power button to cycle through the three light modes: warm white, cold white, and neutral light.
- Press and hold the power button to adjust the brightness infinitely in the current light mode.
- Touch the power button again to turn off the lamp.

Connecting to a Bluetooth Device:

- Press the power button to turn on the lamp.
- On your Bluetooth device, search for “MERKURY BT133” in the list of available devices.
- Select “MERKURY BT133” to connect. An alert will sound indicating the speaker is connected
- You can now play music through the speaker.

TROUBLESHOOTING

No Power

Recharge your TouchSound speaker using the included USB type C charging cable.

[Manualsum](#)

If not working try using a different cable.

Music is not playing Make sure your Bluetooth® device has A2DP profile. over Bluetooth® Check if both devices are paired and connected over Bluetooth®. Restart the speaker to reconnect your Bluetooth® device.

Bluetooth® device will not reconnect with the speaker Navigate to your Bluetooth® settings menu on your Bluetooth® device, tap “MERKURY BT133” and select “Forget”. Now follow the steps to pair your device again.

TECHNICAL SUPPORT

If you are experiencing problems, do not attempt to fix the product by yourself or return it to the store you bought it from.

Please refer to the user manual or just contact our helpful support team:

Merkury Innovations

45 Broadway, 3rd Floor,

New York, New York 10006

www.merkuryinnovations.com

support@mercuryinnovations.com