

# [Magene eBike LED Display DY12 User Manual](#)

## [Manualsum](#), simplified manuals

### Table of Contents

- [Magene eBike LED Display DY12 User Manual](#)
  - [Product Introduction](#)
  - [Appearance:](#)
  - [Specification:](#)
  - [Dimension](#)
  - [Pin Connection Definition](#)

# Magene eBike LED Display DY12 User Manual

Magene eBike LED Display DY12 User Manual

Model: P0203288A

[\(2ALZG-A308\)](#)



## Product Introduction

**Category:** eBike LED Display

[Manualsum](#)

**Model:** P0203288A




## **Appearance:**



## **Specification:**


<b>Rated Voltage (DCV)</b>	36V/48V
<b>Working Temperature (°C)</b>	-20 ~ 50
<b>Storage Temperature (°C)</b>	-25 ~ 55
<b>Waterproof Level</b>	IPX6
<b>Display Type</b>	LED
<b>Assist Level</b>	4 Levels (Including AUTO)
<b>Light Sensor</b>	Available
<b>Walk Assistance</b>	Available
<b>Light On/Off</b>	Available
<b>Data Display</b>	Assist Level, Battery Capacity, Error Code, etc.
<b>APP</b>	Available
<b>Communication</b>	CAN BLE
<b>Upgrading</b>	OTA Upgrading

# Dimension



**Display size:** 82.03\*54.46\*42.75mm, adapted handlebar diameter: 22.2mm

## Pin Connection Definition



Category	No.	Color	Definition
	1	Red	Battery
	2	Black	GND
<b>Pin Connection</b>	3	Yellow	CANL
	4	Green	CANH
	5	Blue	IO / Lock Line