XOG-OE1 Headphones User Manual

Manualsum, simplified manuals

Table of Contents

- XOG-OE1 Headphones User Manual
 - What's in the box
 - Operating Instructions
 - Lighting effect display:
 - HOW TO TURN ON HEADPHONES
 - Specifications
 - Important Notes
 - Product Pollution Index
 - Warranty terms

XOG-OE1 Headphones User Manual

XOG-OE1 Headphones User Manual

MUZEN Sway Shake Open-Ear Headphones User Manual

Shenzhen Airsmart Technology MUZEN Sway Shake Open-Ear Headphones User Manual

FCC id: 2ALXL-OE1I


To all users

Thank you very much for using our products. This product is a new rear-hanging headphone product launched by the OG sub-brand of the Maowang audio brand. It inherits the product experience of Maowang products, which is "good-looking, good-sounding, easy to use and fun", allowing you to connect with your favorite music and sound content more conveniently and easily. It is not only small and portable but also easy to operate, suitable for multiple scenarios, and we hope to bring you a high-quality listening experience. Note: Since this product is battery- powered, in order to give you a better product experience, we recommend that you charge it for two hours before using it when you get it.

What's in the box

- 1. Headphones x1
- 2. Usb Cable x1
- 3. Manual x1
- 4. Warranty Card x1

Operating Instructions



- 1. Is the headphone touch area **Note: Only area 1 supports touch control
- 2. Charging port
- 3. Light display area

Lighting effect display:

- 1. Battery display: The breathing lights on the left and right sides flash when charging, and turn off after 3 minutes of full power
- 2. Low battery: The light flashes and there is a voice prompt of low battery

HOW TO TURN ON HEADPHONES

When headphones are off, touch the R area for two seconds to turn on.

Function

Instructions For Use

Switch On Switch Off Bluetooth Reset Play / Pause Forward Answer / Hun up a call Reject a call

Third-party inbound call answering

Wake up voice assistant

Lights on / off

Touch R area for 2s
Touch R area for 3s
Quick tap R area 5 times
Quick tap R area 2 times
Touch R area for 1s and release
Touch R area 2 times
Touch R area for 1s

Quick tap R area 2 times

Quick tap R area 3 times

Quick tap R area 1 time and then long pres

for 1s

Specifications

• Product Name: Sway Shake Open-Ear Headphones

• Model: XOG-OE1

Bluetooth version: 5.3
Speaker size: Ф0.63in
Size: 4.4in x5.2in x 2in
Net weight: 0.05lb
Battery: 80mAh

• Frequency response range: 20Hz-20KHz

Charging port: Type-C

• Charging voltage: DC 5V [X 1A

• Warranty period: 1 year

Manufacturer: Shenzhen Airsmart Technology Co., Ltd.

Add.: Room 1202, Block A, Guanggqi Future Center, Gaoxin South 4th Road, Nanshan, Shenzhen, China

Contact: info@muzenaudio.com

Made In China

***Note: Since this product uses Bluetooth connection, in daily use, it may be affected by factors such as the environment, mobile phone brand, and usage behavior. It is normal to have short and slight sound jams during music playback.

Important Notes

To ensure safety, please read and follow the following safety instructions in detail:

 The manufacturer has the right to make some detailed modifications or adjustments to the specifications and product details of this product without notifying the user.

Manualsum

- 2. Please use the product in a dry environment.
- 3. The product should not be close to or in contact with exposed fire sources.
- 4. The product is waterproof grade IPX5, but it is necessary to pay attention to certain waterproof and moisture-proof in daily use.
- 5. The normal operating environment temperature of this product is 0-45°. It is recommended not to use this product under environmental conditions exceeding this.
- 6. Do not modify, repair or dismantle this product without authorization, otherwise, you will not be able to enjoy the warranty service.
- 7. If consumers use a power adapter for power supply, they should purchase a power adapter that has obtained CCC certification and meets the standard requirements.
- 8. Note that if the battery is not replaced properly, there is a risk of explosion. If necessary, please go to a professional repair shop. After replacing the battery, this product will no longer enjoy warranty service.

Product Pollution Index

	Name a	and conten	t of toxic s	ubstances in t	he product		
Component name		Toxic and hazardous substances or elements					
Structural components	Lead (Pb)	Cadmiu m (Cd)	Mercur y (Hg)	Hexavalent chromium (Cr6+)	Polybrominat ed biphenyls (PBB)	Polybrominated diphenyl ethers (PBDE)	
Motherboard	2229	0	0	0).239 O	報酬 差 2229	
Battery	0	O	0	<u>198</u>	0	O ### 2229	
Wires	2229	0	0	0	O	資産	
Speakers Screws	(M)	O 188	0	0	0	0 998 2 223	
Packaging material	s O	O	0	O	O = 22729	O ### = 2223	

O: Indicates that the content of the hazardous substance in all homogeneous materials of the component is below the limit requirements specified in SJ/T113642014

X: Indicates that the content of the hazardous substance in at least one homogeneous material of the component exceeds the limit requirements specified in SJ/T113642014

Warranty terms

1. Enjoy one year of free warranty service from the date of purchase.