

Shenzhen chengtai electronic and technology Portable Wireless Speaker User Manual

Manualsum, simplified manuals


Table of Contents

- [Shenzhen chengtai electronic and technology Portable Wireless Speaker User Manual](#)
 - [PRODUCT SPECIFICATIONS:](#)
 - [PRODUCT FEATURE:](#)
 - [KEY AND SLOT FUNCTION:](#)

Shenzhen chengtai electronic and technology Portable Wireless Speaker User Manual

Shenzhen chengtai electronic and technology Portable Wireless Speaker
User Manual

FCC id: [2A86Y-TG-411](#)



PRODUCT SPECIFICATIONS:

- Wireless: V5.3

Support: L2CAP/A2DP/AVCTP, can receive AUDIO signal and control the AUDIO device.


Support HSP//HFP(Handsfree profile), with HANDS-FREE functions.

- Working distance:10M
- SNR: =90db
- Battery: 3.7V about 2400mAh
- Normal volume playing time: about 4H
- Speaker driver: $\phi 45\text{mm} \times 2$
- Speaker Power: 4Q/8W * 2
- Frequency response:120Hz-20KHz
- Unit size: 135+136+71.3mm
- Unit weight: about 561g (not includ accessories)
- Charging:5V/1.8A
- Charging time:about 2.5H

PRODUCT FEATURE:

1. International advanced wireless chip and circuit design techniques, support wireless devices.
2. With FM function, can search radio station broadcast automatically.
3. With Hi-Fi speaker, to make sure the clear and bright sound.
4. Support Micro SD card and USB card, play MP3 format audio.
5. The wireless working distance is 10 meters.
6. With AUX line in, can directly connect the outside devices, for example, tablet PC/TV/cell phones.
7. It will close automatically after 30 mins if disconnect Wireless.
8. A variety of flashing LED lights with different colors, color lights flash follow the melody.
9. Support TWS.

KEY AND SLOT FUNCTION:



1. DC 5V slot: Use the standard type-c USB charging cable for power charging.
2. TF slot: It can decode and play MP3 format audio when put TF card into the slot, Support playing lossless music.
3. USB slot: It can decode and play MP3 format audio when put the USB card into the slot, Support playing lossless music.
4. AUX line in slot: Use the Mini 3.5 head input through outside devices.
5. Power switch: Press long for power on /power off. When play music, (USB card/TF card/Wireless/Line in), short press for "play/pause". In FM mode, press short to search station automatically, press again to stop searching. Under wireless mode with mobile paired, when call coming, press short to answer a call hands-free, press again to hand up, press twice to ring up a call.
6. When play music, press short for next song, long press to turn up the volume.
7. When play music, Press short for last song, long press to turn down the volume.
8. Press short for option of the LED flashing light ,press long to close the LED light .
9. Short press to switch model (TF Card/ USB Card/ Wireless/line in/FM).

TWS: Keep the two speaker under Wireless mode without pairing, press the "M" key for 2-3 seconds either of the speaker until hear a hint, now it is TWS mode . Press the "M" key for 3 seconds either of the speaker to stop TWS after disconnect wireless.

NOTE:

- In the FM mode, Please pull out the antenna to get better FM radio signal.
- If this speaker crash during use, you can press and hold the power button for 8 seconds to reset and shut down.
- USB /TF card pls use FAT32 format.