# Shenzhen Glory Star L15 Bluetooth headphone User Manual

# **Manualsum**, simplified manuals

### Table of Contents

- Shenzhen Glory Star L15 Bluetooth headphone User Manual
  - Specifications
  - What's in box?
  - · Bluetooth Pairing
  - Warning:
  - Charging Function:
    - Case Charging:
    - Earbud Charging:
    - Power On/off:
    - Play/Pause Music
    - Previous/Next Song
    - Volume -/ +
    - Incoming Phone Calls
    - Voice Assistant:

# Shenzhen Glory Star L15 Bluetooth headphone User Manual

Shenzhen Glory Star L15 Bluetooth headphone User Manual

Glory Star L15-BK Bluetooth headphone User Manual

2AS7V-L15



# **Specifications**

- Bluetooth version: V5.4
- Earbud Bluetooth solutions: JL7003
- Case Bluetooth solutions: JL7012
- Bluetooth working frequency: 2.402GHz-2.480GHz
- Frequency response: 20Hz-20KHz
- Earbud battery capacity: 40mAh
- Charging case battery capacity: 400mAh
- Speaker size: 13mm
- Effective distance: 10M
- Play time: Up to 6hours
- Charging time: 4-5hours

# What's in box?

- 1 x Charging cable
- 1 set Eartips

# **Bluetooth Pairing**

- 1. The earbuds will automatically enter the searching and pairing mode when turned on
- 2. Open the Bluetooth settings on your phone to search and pair the speaker. Pairing name: "L15-BK"
- 3. After paired successfully, your phone's audio will play through the earbuds

# Warning:

Read the below warning thoroughly before using your earbuds. Store this manual with product packaging.

### To reduce the risk of injury:

- 1. Keep batteries out of reach of children.
- 2. Do not heat, open, or dispose of battery pack in fire.
- 3. Do not allow metal objects to touch the battery on the device.
- 4. Do not expose battery pack to excessive heat.

# **Charging Function:**

Fully charge the case and earbuds before using for the first time.

# **Case Charging:**

1. Connect the included USB-C cable to the Type-C charging port of the earbud case and the other end into a USB power source to charge your case.

# **Earbud Charging:**

- 1. When the earbud battery is low, it will prompt "battery low" every minute. The earbuds will turn off completely when the batteries are fully discharged.
- 2. Place the earbuds into the charging case and close the case. The charging case will automatically charge the earbuds, and the display on the charging case will show a charging symbol.

# **Power On/off:**

- 1. Open the charging case, and take out the earbuds, the earbuds will turn on automatically
- 2. Place earbuds into the charging case and close the case to turn off.

# **Play/Pause Music**

1. When listening to music, tap the left or right earbud once to play or pause the music.

### **Previous/Next Song**

- 1. When listening to music, double tap the left or right earbud to skip to the previous song
- 2. Triple tap the left or right earbud to skip to the next song

### Volume -/ +

- 1. When listening to music, slide finger down the left or right earbud to decrease the volume
- 2. Slide finger up the left or right earbud to increase the volume

# **Incoming Phone Calls**

- 1. Tap left or right earbud once to answer or hang up
- 2. Tap left or right earbud twice to reject the call

### **Voice Assistant:**

1. Tap left or right earbud 4 times to activate voice assistant