

# **BAUHN Mini Retro Bluetooth Speaker User Manual**

## **Manualsum, simplified manuals**

### Table of Contents

- [BAUHN Mini Retro Bluetooth Speaker User Manual](#)
  - [Security guidance](#)
  - [Technical parameters:](#)
  - [Accessories](#)
  - [Button instruction and Basic Operation:](#)
  - [Button Operation](#)
  - [Battery charging](#)
    - ■ ■ [\\*Remarks:](#)
  - [Bluetooth Pairing](#)
    - ■ ■ [REMARKS:](#)

## **BAUHN Mini Retro Bluetooth Speaker User Manual**

BAUHN Mini Retro Bluetooth Speaker User Manual

Hudson Mini Retro Bluetooth Speaker User Manual

Shenzhen Hudson Technology MINI RETRO BLUETOOTH SPEAKER User Manual

FCC id: [2BHCG-712774](#)



# BAUHN®

## RETRO BLUETOOTH SPEAKER

Thanks for choosing our product.

We hope you will enjoy music.

### **Security guidance**

Before using the speaker, please read our specs clearly and keep it for future reference.

1. Stay away from heat, sharp items, direct sunlight and open fire.
2. Do not insert any metal objects, avoid short circuit.
3. Don't repair the product by yourself, please contact the authorized manufacturer to repair it.
4. Avoid rain, spray and other liquids.
5. If the product is overheated, damaged or falling into the liquid, stop using it.
6. Use the product according to local standards and regulations.

[Manualsum](#)


## Technical parameters:

<b>Bluetooth Version</b>	V5.3
<b>Range</b>	10 meters
<b>Power Supply</b>	DC 5V/1A
<b>Battery</b>	3.7V 500mAh
<b>Charging Time</b>	Approximately 1-2 hours
<b>Speaker Output</b>	5W
<b>Operating Time</b>	Approximately 2-3 hours

## Accessories

- 1\* Bluetooth speaker
- 1\* USB charging cable
- 1\* Audio cable
- 1\* Manual

## Button instruction and Basic Operation:



1. Volume adjustment
2. Volume scale
3. Next song/FM program
4. Power on&off/Play&Pause/Mode Switching
5. Previous song/FM program
6. Bluetooth indicator light
7. AUX audio port
8. USB drive reading
9. TF card
10. Charging port

# Button Operation

Button (4)

- Power on/off: Long press 3~4 seconds
- Play/Pause: short press
- Change Mode: Double press (FM/BLUETOOTH/TF/USB/AUX in)
- When receive calling, short press to answer, double press will refuse the call

Insert audio wire into (7) after turn on the speaker, will into AUX mode automatically

Insert USB to (8) and TF card to (9) to listen music you instore

**FM radio:** Plug in charging cable firstly (Charging cable acts as an antenna, press (4) twice for FM mode, then press (4) for FM station searching, press again to stop the searching. After the searching, it will automatically enter the first channel.

Short press Button (5) for previous music/FM program

Short press Button (3) for next music/FM program

Rotate (1) for Volume adjust

## Battery charging

1. Insert the charging cable DC 5V, connect the USB to the computer or DC adapter. LED indicator light turns red, it means speaker is charging.
2. When the speaker is fully charged, the red indicator will turn off.

### \*Remarks:

- The new battery only needs 2-3 hours for the first time to complete the charge and discharge cycles. Avoid overcharging the speaker.
- If speaker is not used for long periods of time, the battery life may shorten slightly.

## Bluetooth Pairing

Long press button @ for 3 seconds to Power on speaker. This will put it in Bluetooth mode directly. Search and select "Bauhn Speaker" on your phone Bluetooth list, when you hear a voice "Connected", it means connection was successful. Indicator light stays on while Bluetooth is active.

### REMARKS:

If the speaker was previously paired to another device, remove the connection from the old device before pairing to the new device.

[Manualsum](#)

**Distributed by:**

ALDI Inc.

Batavia, IL 60510

[www.ALDI.us](http://www.ALDI.us)

**Contact:** info@xtremetime.com

(US)1-888-204-0934