Shenzhen Yuan Xiu trading J11 Bluetooth Headset User Manual

Manualsum, simplified manuals

Table of Contents

- Shenzhen Yuan Xiu trading J11 Bluetooth Headset User Manual
 - Specifications:
 - Headphone use steps and special instructions
 - Headphone touch function description

Shenzhen Yuan Xiu trading J11 Bluetooth Headset User Manual

Shenzhen Yuan Xiu trading J11 Bluetooth Headset User Manual

FCC id: 2BH8I-J11

TWS(true wireless stereo)earphones J11 Manual



Auto power-On Auto Pairing 5.3

Specifications:

True wireless stereo [TWS), real no wires design, individuateft and right channel, HIF] sound. both the left and right earbud are Blustooth enabled could be used separately, or used as ane pair.

Bluetooth version: V5. 3+EDR {both sides), ultra low consumption

Bluetooth Mode: A2DPLIAHFPLEHSPL2AVRCPLE/DILS

Bluetooth Frequency: 2AGHZ **Bluetooth Range:** 10-15m

Earbud: 30 mah rechargeable Li-ion battery

Battery capacity: Charging dock: 180mahioptional)

Standby time: Bath ears.can stand for 120 hours

Headphone playback timed hours

TalkPlay time:

Manualsum

Headphone use steps and special instructions

- 1. Open the tap cover of the charging box and take out the earphones, {importantnate: Turn on the ro oi switch before opening the charging bax, which isthe premise of the headset automatically turning on)
- Pair with other devices: Open the phone or other device Blustooth settings. search for the Bluetooth name "J11°, cick to connect to Bluetooth
- 3. The headset's placed in the charging bax to enter the charging mode, and theheadsetis automatically tumed off.
- 4. wirehess head phones can be connected separately and separately to other Bluetooth devices.
- 5. wireless haadsat will automatically shut down if it is nat connected to the Bluetooth device for 3 minutes.

Headphone touch function description

- 1. Touch the position In the lft and right ears, dick answerfend the cal, and longpress to reject the cal; Click to play/pause music, double-dick on the previous/nexttrack on the at earphones, and triple click on the volume increase/decreaseon the left/right earphones; Short press far 2 seconds to wake up Sri, long press totum it on or off.
- 2. Tum off and an again, the headset will automatically connect back to the phor;
- 3. The headset is a twa<channel call, there & sound in both left and nght ears:
- 4. Earphone msi playback time is about 4 hours, talk time is about 4 hours, standirytime is about 24 hours;
- 5. The charging base battery capacity is 1B0mA, and the headset battery APACS 30mA;
- 6. The charging voltage of the charging box is 5v;7. The charging time of the earphone is about 1.5 hours, and the charging bos about 1.5 hours;
- 7. The charging bas can charge the headset about 3 times;
- 8. The charging flashes whila charging