

[Disney 951 Bluetooth Earphones User Manual](#)

[Manualsum](#), simplified manuals


Table of Contents

- [Disney 951 Bluetooth Earphones User Manual](#)
 - [Summary](#)
 - [How to match the device](#)
 - [Function overview](#)
 - [Function](#)
 - [Charge the headset](#)
 - [Charge the charging box](#)
 - [Product parameters](#)
 - [TIPS](#)
 - [WARNING](#)

Disney 951 Bluetooth Earphones User Manual


Disney 951 Bluetooth Earphones User Manual

([2BGLV-951](#))



Summary

TWS wireless Bluetooth headset supports mobile phones, tablets and laptops Bluetooth devices such as computers



How to match the device


1. When using for the first time, open the cover of the charging compartment, open the Bluetooth matching search of the mobile

[Manualsum](#)

phone, click the Bluetooth matching name searched on the mobile phone: 951, and select it to complete the matching.

2. After there is matching record, the cover will be automatically connected (the Bluetooth of the mobile phone is on), and it is no need for manual matching search.
3. **Note:** if the indicator light of the charging compartment is not on, please use the Type-C cable to charge the charging box, and the orange light flashes.

Function overview



Function

Power-on

When the cover is opened, the headset will be power on automatically.

Power-off


Put the headset back into the charging box and it will be power off automatically when the cover is closed.

Connection back

After opening the cover, it is automatically connected back to the design of the last connection.


Call rejection

Long press the left / right ear for 2 seconds, or reject the call with the mobile phone




Answer/End

Click the left/right ear, or answer the call with your mobile phone.



Pause / Play

Click the left or right ear to pause or play music.




Switch between previous and next track

Previous track

double click the left ear touch area

Next track


double click the right ear touch area



Volume up and down


Volume -: three clicks on the left ear touch area

Volume +: three clicks on the right ear touch area



Voice assistant

long press the left / right headphones for 2 seconds to start the voice function



Charge the headset

Put the earphone back into the charging compartment and close the cover to charge automatically. The Green light in the charging compartment is long on.

When the power of the headset is too low, the headset will have a prompt tone (Beep).

Charge the charging box

Please use Type-C charging wire to charge. When charging, the Orange light flashes.

When the charging box is full, the green Orange long on.

Note: Please use the 5V/1A charger when charging the product.

Product parameters

Model: 951

Bluetooth version: V5.4

Transmission range: 10M (straight and barrier free)

Headset charging time: about 1 hours

Charging time of charging box: about 1 hour

Music playing time: 4-5hours

Headset battery capacity: 3.7V/28MA

Battery capacity of charging box: 3.7V/180 MA

Please properly arrange the use time and adjust the volume. Using headphones for a long time may damage your hearing”

TIPS

1. Before using the earphones, please read the manual carefully and keep it for future reference.
2. The earphones need to be fully charged prior to first-time use.
3. If the earphones are left unused for over two weeks, please recharge them periodically.
4. Please use chargers made by a qualified manufacturer.
5. If the mobile phone cannot find the Bluetooth headset, please check whether the headset is in Pairing mode. If not connected for a long time, the headset will exit pairing mode.

WARNING

1. Never disassemble or modify your earphones for any reason to avoid damages and danger.
2. Do not store the earphones in extreme temperatures (0°C to 45°C).
3. Avoid using the indicator close to the eyes of children or animals.
4. Do not use these earphones during a thunderstorm to avoid irregular function and the increased risk of electric shock.
5. Do not use harsh chemicals or strong detergents to clean the earphones. Keep the earphones dry.
6. Keep the headset and charging box dry.

Disney 951 Bluetooth Earphones User Manual