

LANIX XBOOK GO LAPTOP USER MANUAL

Manualsum, simplified manuals

Table of Contents

- [LANIX XBOOK GO LAPTOP USER MANUAL](#)
 - [Preparation](#)
 - [Open your computer](#)
 - [Adjust the screen of your device](#)
 - [Connect the power adapter to your computer and to a power outlet](#)
 - [Power On](#)
 - [Description of components and ports.](#)
 - [Use Wireless LAN Network for Internet Connection](#)
 - [Precautions.](#)
 - [Care and Recommendations](#)
 - [Cleaning Suggestions](#)
 - [Recommended Environment](#)
 - [Transporting the Laptop](#)
 - [Service and Professional Support](#)
 - [Authorized Service Centers](#)

LANIX XBOOK GO LAPTOP USER MANUAL

LANIX XBOOK GO LAPTOP USER MANUAL

([2BHAF-BL14CA1](#))

Please read this manual before starting to use the laptop.

It is not recommended to install additional hardware to your new system until you finish its initial setup.

[Manualsum](#)

Preparation

Before setting up and using your personal computer, please read the safety and operating instructions.


Open your computer



Adjust the screen of your device



Connect the power adapter to your computer and to a power outlet




Power On



Description of components and ports.

Vista frontal.



Vista inferior.



Vista lateral izquierda.



Vista lateral derecha.





1. Webcam.
2. Webcam security lock.
3. Screen.
4. Touchpad lock LED.
5. Caps lock LED.
6. Power LED.
7. Microphones.
8. Hidden touchpad buttons.
9. Speakers.
10. Expansion slot cover.
11. Charging indicator LED.
12. Power connector.
13. USB 3.0 ports.
14. HDMI port.
15. Micro SD card reader.
16. Headphone port.
17. Kensington lock hole.


Use Wireless LAN Network for Internet Connection


To enable/disable the wireless network, follow these steps:


1. Click on the Wi-Fi icon located in the bottom right corner of your desktop.


 cert_google
Segura

 EA9500
Segura

 GARLX2.4GHz
Segura

 ValONE
Segura


 CALIDAD_3
Segura


 Celulares
Segura


 DIRECT-80-HP M132 LaserJet

Configuración de red e Internet

Cambia la configuración, por ejemplo, crea una conexión de uso medido.


Wi-Fi


Modo avión



Zona cubierta móvil

[Manualsum](#)



10:32 a. m.
29/06/2018

2. A new window will be displayed, in which it is necessary to click on the Wi-Fi option to enable or disable wireless networks.



Precautions.

Care and Recommendations

The following information is aimed at obtaining the best performance and a long life for your laptop. If you need technical answers or more specialized information, call 52 (662) 10 90 807.

- If you choose to keep your laptop turned on while you are not interacting with it, it is recommended that you activate the screensaver options as well as the energy-saving functions.
- If a power cable is damaged, disconnect it immediately.
- Disconnect the power cables if your device has been exposed to rain or any excessive moisture.
- Disconnect the power cables if the device has fallen or somehow been strongly impacted.
- Disconnect the power cables whenever you clean the device or perform maintenance on it.

Cleaning Suggestions

- Before any cleaning operation, your device must be turned off and preferably disconnected.
- Do not use aerosol liquids, solvents, or abrasives that could damage the finish of your laptop.
- Try not to spill liquids on your keyboard as it can be damaged by anything that leaves sticky residues.

Recommended Environment

Your laptop can tolerate more or less the same temperature that you find comfortable, but do not expose it to direct sunlight, rain, or excessive moisture. Adequate ventilation is very important to extend the life of your laptop. Make sure there are clearances of 10 to 15 cm on both sides and the backside of your device.

Transporting the Laptop

There may be a need to transport the device, either to claim a warranty, change its location, or resell it. In these cases, it is recommended to use the original packaging as it provides the best protection for your device.

Service and Professional Support

Your equipment requires periodic preventive maintenance, for which it is highly recommended to go to the nearest Lanix service center or to your authorized computer distributor.

This service is especially necessary when there is dust and humidity in the normal working environment.

[Manualsum](#)

At the nearest Lanix service center or with your authorized computer distributor, you will receive the latest information about the technical aspects of your computer as well as the necessary parts and accessories to provide immediate response to your support requirements.

They usually offer preventive and corrective maintenance plans, in addition to being the conduit to support the warranty that the factory extends for its products.

Authorized Service Centers

At the nearest Lanix service center or with your authorized computer distributor, you will receive the latest information about the technical aspects of your computer as well as the necessary parts and accessories to provide immediate response to your support requirements.

They usually offer preventive and corrective maintenance plans, in addition to being the conduit to support the warranty that the factory extends for its products.

PLACE WHERE PARTS, COMPONENTS, CONSUMABLES, AND ACCESSORIES CAN BE OBTAINED.

LANIX DE AMERICA S. A. DEC. V.

Address where the warranty will be validated: Carretera Internacional Hermosillo a Nogales Km. 8.5 Col. San Luis Hermosillo, Son. C.P. 83160

Email: germand@lanix.com

Contact: (662) 109-0807