

TRUSTSTONE MUSHROOM LED SPEAKER LED LAMP User Manual 2BBPL-WL- MSLMSP

Manualsum, simplified manuals

Table of Contents

- [WONDERLIT MUSHROOM RED LIGHT & WIRELESS SPEAKER](#)
 - [PRODUCT SPECIFICATIONS](#)
 - [PACKAGING CONTENT](#)
 - [PRODUCT INSTRUCTIONS](#)

WONDERLIT MUSHROOM RED LIGHT & WIRELESS SPEAKER

(2BBPL-WL-MSLMSP)



PRODUCT SPECIFITATIONS


1. Model : WL-MSLMSP-CLR
2. Speaker Power: 3W
3. Battery capacity: 1200 mAh
4. Voltage: 5V
5. Power Input: USB-C
6. IP Rating: IPX4
7. Lumens: 1500-1700
8. Color Temperature: 2700k-6000k

PACKAGING CONTENT

1. Mushroom LED Light x1
2. USB-C Cable x1
3. Remote Control x1
4. User Manual x1

PRODUCT INSTRUCTIONS

1. Touch the lighting fixture to turn on and off the light for 2 seconds, and touch the same position on the top to adjust the brightness of the light. It is 100%, 50%, and 25% (see the page logo). There is a red switch button at the bottom of the product. Press and hold the bottom switch button for 2 seconds to turn on Bluetooth and lights. Do not touch the middle audio part at the top. Press and hold the top metal ring for 2 seconds to turn on the lights, and tap repeatedly to cycle through the 7 color options.
2. The remote control can adjust the functions of red, green, blue, white, pink, golden light, fast flashing, slow flashing, breathing dimming, automatic seven color dimming, and flashing. Bluetooth mode, connected to a phone or computer, allows one phone to control two desk lights, brightness, music control, sound control, selection mode, switch, previous and next tracks. Any mobile phone or other device can be connected to Bluetooth without checking. (Bluetooth name: XH-016).
3. The remote control comes with a battery for use. Before use, remove the battery protection film and use the USB Huawei data cable for more sensitive and convenient buttons. When the battery is out of charge, it can be charged through a USB cable and used in indoor environments with a seasonal protection level of P20.
4. Connect the USB cable to the charging port of the lamp base, and connect the other end to the power socket. The blue light indicates that charging is in progress. Please continue charging for more than 5 hours to ensure optimal power. When fully charged, the blue or green light on the USB socket will turn off. Full charge can last for more than 10 hours of continuous use. We recommend fully discharging the battery during the first 10 uses to ensure optimal battery condition. When the battery runs out, charge it as soon as possible: the battery life will be shortened if there is no electricity for a long time.
5. Please use original rechargeable batteries and avoid using regular batteries under any circumstances. This may cause danger. If you need to replace the battery, please contact the manufacturer or distributor company.
6. Removing the battery: Ensure that the product is not powered on. Loosen the bottom screw on the opposite side, remove the connector, and place the battery in a suitable processing center.



Use the provided remote to turn the product on or off, to change the light color, or to select from the available lighting modes.

Adjust Light Level:

Use the buttons to adjust the brightness of the product.

Power ON/OFF:

Easily turn the product on and off remotely.

Select Colors:

Select your favorite color, or a color that matches your environment or mood, from 16 available options.

Select Light Mode:

Choose from one of 4 preprogrammed lighting modes for your favorite effect.