

XINVO INDUSTRIAL **AudioAnchor Wireless** **Speaker User Manual**

Manualsum, simplified manuals

Table of Contents

- [XINVO INDUSTRIAL AudioAnchor Wireless Speaker User Manual](#)
 - [SPECIFICATIONS](#)
 - [TO PAIR SPEAKER](#)
 - [FUNCTIONS](#)
 - [TWS:](#)

XINVO INDUSTRIAL AudioAnchor Wireless Speaker User Manual

XINVO INDUSTRIAL AudioAnchor Wireless Speaker User Manual

FCC id: [2ARZK-98400](#)

SPECIFICATIONS

- Wireless version: 5.3
- Speaker power: 5W*1
- Battery capacity:450mAh
- Input:5V/1A

TO PAIR SPEAKER

1. Press and hold the power on/off button for 3 seconds to turn on the speaker.
2. On your device's wireless connection menu, find and select "AudioAnchor" .
3. After the connection is completed, a prompt sound will indicate that speaker is paired with device.
4. When the battery is low, you will hear "low battery, pls charge"

[Manualsum](#)

FUNCTIONS

1. Long press the power on/off button to turn on/off, short press to play/pause
2. Short press “-“to previous song, long press to decrease volume
3. Short press “+”to next song, long press to increase volume

TWS:

Power on auto couplet, double click “+” to disconnect and connect TWS