[TK-PRO Phone Holder User Manual](#)

[Manualsum](#), simplified manuals

Table of Contents

TK-PRO Phone Holder User Manual

TK-PRO Phone Holder User Manual

([2BHBZ-TK-PRO](#))

After-sales email: TKservice001@outlook.com

Packing list

Phone Holder*1

Remote Control*1

(This direction is the front
of the remote control)

Type-C Cable*1

User Manual*1

Phone holder function introduction

1. Phone Installation

2. 360 degree rotatable phone stand

Buttons function introduction

NO.	Buttons	Function	Operation	Notes
1		Power on	long Press 5S	Power off state
2		Manual Power off	long Press 5S	Power on state
		Auto Power Off	Power on and unconnected state, automatically power off after 3 mins	Not connected state
3	△	Up/Flip up	Single click	
4	▽	Down/Flip down	Single click	
5	◁	Left/Flip left	Single click	
6	▷	Right/Flip right	Single click	
7	OK	Confirmation	Single click	

8	OK	Single like	Double click	
9	OK	Continuous likes	Long press 3S	
10	OK	Exit continuous likes	Long press 3S	In the continuous likes state
11	📷	Take photos	Single Click	
12	📷	Photo focus	Long press 3S	In the photo state
13	OK	Photo focus	Single click	In the photo state
14	📷	Volume +	Single Click	Not in the camera state
15	📷	Volume -	Double click	Not in the camera state
16	📷 OK	Disconnect currently pairing	Press 2 buttons at the same time，red and blue lights flash alternately	Disconnect currently connected device
17	△	Horizontal screen switch	Long press 3S	Only supports horizontal orientation on one side

Light status introduction

NO.	Lighting status	Function
1	Red light is always on	Charging
2	Light off	Fully charged
3	Red light flashes	Low battery
4	Red and blue lights flash alternately	Pairing search status
5	Blue light flashes once	Remote control is operated once
6	Red and blue lights flash alternately 3 times	Horizontal screen switch

# Guides for Set-up

Step 1:

iOS devices must first turn on AssistiveTouch (The iOS system version is higher than 14.8) Settings>Accessibility>Touch>Turn on Assistive Touch (Android phones do not have the dots)

Step 1

Step 2:

Long click the 5S "Camera" button to Power On (Red and blue lights flashing)

Step 2

Step 3:

Pair the Bluetooth "TK-Pro" (Lights off)


Step 3

**Step 4:**

Open the software and operate it

Using on Camera/Video

· Single click： Switch camera mode

· Single click： Switch camera mode

· Single click： Photo focus

· Single Click： Take photos
· Long press 3S： Photo focus

Using on TikTok (Or other video playback software)

- Single click: Previous video
- Single click: Next video
- Single click: Pause/Playback
- Double click: Single like
- Long press 3S: Continuous likes
- Long press 3S: Exit continuous likes

# How to switch the video to a horizontal screen?

1. Turn on the screen lock of the phone
2. Flip the phone to the left to landscape mode. Then long press 3S "Up" button to switch to horizontal screen operation mode
3. Single click "up" button: play the previous video Single click "down" button: play the next video Single click "OK" button: pause/play
4. Flip your phone to portrait mode. Then long press 3s "Up" button to exit the horizontal screen mode

Using on E-book

Two-Step Solution Scrolling Up/Down Too Far

1. Click to adjust text

2. Turn off continuous scrolling

(Note: Only available for Kindle APP not for Kindle devices)

Product Parameters

Remote control

Frequency (Hz): 20-20 khz

Model: TK-PRO

Communication distance: 10 meters

Battery capacity: 300 Mah

Charging time: about 1.5 hours

Charging interface: Type-C