Shenzen LED Projector User Manual 2AZFE-ONO3PRO

Manualsum, simplified manuals

Table of Contents

- Shenzen LED PROJECTOR User Guide
  - 01. Remote control introduction
  - 02. Host Appearance and Function Description
  - 03. Interface Connect
  - 04. Setting
  - 05. APP
    - First Step
    - Second step
  - 06. Miracast and DLNA/MagicCast
  - 07. Speaker Mode Setting
    - First Step
    - Second step
    - Third step
  - 08. E-manual
    - First Step
    - Second step
  - 09. Electronic Focusing
    - Electronic focusing
  - 10. Projection Distance & Size
  - 11. Technology Features
  - 12. Unload The Dust Net and Clear
    - First Step
    - Second step
    - Third Step
  - 13. Projector Installation
    - Desktop use
    - Hoisting and use

Shenzen LED PROJECTOR User Guide



Manualsum

01. Remote control introduction

Power button:
Turn on/off

Mute button:
Mute

Focus button:
Adjust focal distance

Input button:
Choose to enter the Application Center, HDMI

Back button:
return to last step

Quick Menu Key:
Enter the setting pop-up window interface

Home button:
short press and return to the homepage

Direction Buttons:
Up Down
Left Right
OK

Volume button:
Volume-, Volume+

NETFLIX:
Direct enter NETFLIX

YouTube:
Direct enter YouTube

Prime video:
Direct enter PrimeVideo

To avoid power shortage, please do not mix up the old and new batteries. To avoid battery leakage and corrosion, please take the battery out if do not use remote control for a long time.

Manualsum

02. Host Appearance and Function Description



HDMI

USB

Headphone

Power switch

Power input

Manualsum

03. Interface Connect





Manualsum

04. Setting

- On the homepage, select Settings



- WIFI Setting



- Bluetooth Setting



- Input/HDMI Setting



05. APP

First Step

- On the homepage, select My APPS–Netrange

Manualsum



Second step

- You can search for what you need



06. Miracast and DLNA/MagicCast

- On the homepage, ScreenCast Assistant

Manualsum



- Miracast



- DLNA

Manualsum



- MagicCast



07. Speaker Mode Setting

First Step

- On the homepage, select My APPS–Bluetooth Speaker

Manualsum



Second step

- Connect to the Bluetooth for playing music



Third step

- Playing music

Manualsum



08. E-manual

First Step

- On the homepage, select My APPS–E-manual



Second step

- For more information, please refer to the E-manual field inquiry.

Manualsum



09. Electronic Focusing

Electronic focusing

Press the “-” and ” +” buttons on remote control to adjust the clarity

Manualsum





10. Projection Distance & Size

Manualsum



11. Technology Features

Imaging Technology	TFT LCD
Native Resolution	1920*1080
Light Source	LED
Focus Mode	Manual Focusing
Projection Distance	1.4 – 6.0 (m)
Screen Size	48-200 Inches
Aspect Ratio	16:9 and 4:3 and Auto Fit
Power Input	100V-240V-50/60HZ
Input	USB*1/HDMI*1
Output	Earphone
Speaker	4Ω 3W
Unit Size	200*167*80mm
Net Weight	1.11KG
Throw Ratio	1.35:1

Manualsum

12. Unload The Dust Net and Clear

First Step

- Take out dust net from the projector bottom



Second step

- Clean the dust net
- For your safety,please cut off the power before cleaning

Third Step

- Align the bottom bayonet and install the dust net

Manualsum



13. Projector Installation

Desktop use



Manualsum

Hoisting and use



Please read the notes carefully:

1. To ensure stable power supply, please use national standard power cable and power cord with grounding;
2. Please use the type of power supply indicated on the projector and the supplied power supply for power supply;
3. Please do not disassemble the machine yourself, otherwise the company will not undertake warranty service;
4. Do not look directly at the projector lens while the machine is working, it might cause damage to your eyes;
5. To prevent clogging the projector vents, do not cover them with cloth, carpet or other materials;
6. This projector does not have waterproof function, please keep it away from rain, moisture and other items containing liquid such as vase, cup, etc;
7. To prevent electric shock, please keep the projector away from rain, water or moisture;
8. Cut off the power supply if do not use this projector for a long time;
9. Use the original foam or other anti-shock material to protect projector if you need transport this projector;
10. If you find the projector has problems, please contact with the supplier, do not repair by yourself;
11. To extend the projector life span and protect your eyesight, we suggest you may have a break after 3-4 hours using.

Manualsum