

[XGRIDS Lixel L2 PRO User Manual](#)

[Manualsum](#), simplified manuals


Table of Contents

- [XGRIDS Lixel L2 PRO User Manual](#)
 - [Product Overview](#)
 - [About Lixel L2 PRO](#)
 - [Operation](#)
 - [Battery installation](#)
 - [Tripod Installation](#)
 - [Function Button](#)
 - [Indicator Light Description](#)
 - [Data Copy Description](#)
 - [Battery](#)
 - [Maintenance](#)
 - [Matters needing attention](#)
 - [Appendix](#)
 - [Specification](#)

XGRIDS Lixel L2 PRO User Manual

XGRIDS Lixel L2 PRO User Manual



([2A9PI-LIXELL2](#))



Product Overview

Lixel L2 PRO, a highly integrated and lightweight handheld 3D reconstruction device. With the 3D real-time reconstruction algorithm, Lixel L2 PRO can directly obtain the true color point cloud. The results are calculated in real time and can be viewed and used immediately.


About Lixel L2 PRO



Operation

Battery installation


1. Open the lever.
2. Insert the battery into the bottom of the device along the guide dovetail slot. Ensure that the battery is inserted into the correct position.
3. Press the lever back and lock the battery tightly.



Note: An unsecured battery may cause the device to slip.

Tripod Installation

The bottom of the battery has threaded holes. Screw the tripod in and place the device in a flat position.



Function Button

Function	Operation	State
Open	Long press 4 seconds	The indicator light turns from slow blinking blue light to steady green light;
Close	Long press 4 seconds	Indicator light off;
Start Scanning	Double Click	When the device is in standby state, double-click the indicator. The indicator status changes from steady green to blinking green at short intervals and then to blinking green at long intervals. And the lidar starts to rotate, that is, the scan is started successfully.
Stop Scanning	Double Click	When scanning, double click the button, the indicator state will change from green slow flashing to green quick flashing and then to steady green. Meanwhile, the lidar will stop rotating and the scanning will be stopped successfully.

Note:

1. Please put the device on the flat table before starting the scan. After starting the scan, the device can be moved for scanning only after the lidar rotates.
2. It takes about 10 seconds to start scanning.
3. During the scanning stop, if the indicator blinks green quickly, scanned files are being stored. If the power is off at this time, files may be lost or saved incompletely.
4. After the scan is stopped, the waiting time for stored files may be long, it's depending on the size of the scene being scanned.

Indicator Light Description

Indicator blinking status	Significance
None	The device is not started.
The blue light blinking slowly	The device is starting up.
Blue light normally on	USB disk mode
Green light normally on	The device is in standby state
The green light blinking fast	The scan is being started/stopped
The green light blinking slowly	Scanning
Yellow light normally on	The device is not activated
Red light normally on	Serious device failure


Data Copy Description

Use the USB cable that matches the device. Connect the device to the computer in standby mode and turn on the USB mode in the App. After identifying the device, the data can be copied.

Note:

1. The USB mode is automatically disabled after a restart.
2. After turning on the USB mode, you need to manually turn off the USB mode if you want to continue scanning without shutting down or power off.
3. Using a non-standard USB cable may cause slow data copy. Or may cause forward insertion can be used, reverse insertion can not be used.

Battery



Use the standard charging cable and connect the charging adapter to the battery to charge the battery.

Charging time: about 2 hours. During the charging process, the indicator light will show the current electric quantity.


Please refer to the following table for details.

Indicator blinking status	electricity
Only one green light on	0-24%
Two green lights on	25%-49%
Three green lights on	50%-74%
Four green lights on	75%-99%

Maintenance

The storage status of the device is as shown in the figure below. After use, remove the battery and put it back into the storage box according to the figure.

Note: It is a precision device, not storing as required may cause damage to the device.



Matters needing attention

1. Lixel L2 PRO is a precision device. Falling or being hit by external forces may damage the equipment and result in abnormal or inaccurate accuracy.
2. When using a tripod, ensure that the tripod and the device are tightened to prevent the device from falling.
3. Ensure that after Lixel L2 PRO is turned on, lidar rotation is not blocked by external forces.
4. Lixel L2 PRO waterproof grade is IP54, do not use in the environment beyond this protection grade. Use a soft dry cloth or standard cleaning cloth to clean the device. Keep the lidar and the camera clean, do not touch it directly.
5. The device will generate heat during use. Please do not touch the fuselage to avoid burns.
6. Do not cover or touch the heat sink during use. The device may automatically shut down when the temperature is too high.

Appendix

Specification

Parameter	XGRIDS
In put	14.4V
Power	<30W
Size	138mm*90mm*381mm
weight	About 1.9kg
Data socket	USB 3.1 Gen2
Internal storage	1T SSD
Wireless module	Wifi, Bluetooth 802.11a/b/g/n/ac, 2.4~2.4835Ghz or 5.15~5.85Ghz
Operating Temp Range	-20°C~50°C
IP level	IP54
Shell material	aviation aluminum
Power supply	Removable integrated battery
Single usage duration	1.5h
Battery capacity	46.8wh
Camera Quantity	3
Visually assisted positioning	Support
APP WIFI distance	20 M without interference
The laser line number	16
Laser level	Class 1 / 905nm
Relative accuracy	<2cm
Repeat accuracy	<1cm

[Manualsum](#)

Scan effective distance	120m
FOV	360° × 270°
Scanning mode	Mobile
Point cloud frequency	320000 points /s
Environmental requirements	Indoor/Outdoor
Single working duration	60mins
Resume breakpoint	Support