Keychron Technology (Shenzhen) 2BGKB-B1PRO Wireless Mechanical Keyboard User Manual

Manualsum, simplified manuals

Table of Contents

- B1 Pro Ultra-Slim Wireless Keyboard
 - User Manual
 - IN THE BOX:
 - 1. Connect 2.4GHz Receiver
 - 2. Connect Bluetooth3
 - 3. Connect Cable
 - 4. Switch To The Right System
 - 5. Switch Between Function And Multimedia Keys
 - 6. Reset Keyboard
 - 7. The Keychron Launcher App
 - B1 PRO ULTRA-SLIM WIRELESS KEYBOARD SPECIFICATIONS
 - B1 PRO ULTRA-SLIM WIRELESS KEYBOARD OVERVIEW
- LED STATUS OVERVIEW

B1 Pro Ultra-Slim Wireless Keyboard


User Manual

IN THE BOX:


- 1. Keychron B1 Pro Ultra-Slim Wireless Keyboard x 1
- 2. Type-C Cable x 1
- 3. Type-A to Type-C Adapter x1
- 4. Type-A 2.4GHz Receiver x 1

- 5. Quick Start Guide x 1
- 6. Silicone Skin x 1

1. Connect 2.4GHz Receiver



2. Connect Bluetooth3




3. Connect Cable




4. Switch To The Right System

Please make sure the system toggle on the top right corner has been switched to the same system as your computer's operating system.




5. Switch Between Function And Multimedia Keys



6. Reset Keyboard

Hold fn + J + Z for 4 seconds.



7. The Keychron Launcher App

Please visit launcher.keychron.com to access the Keychron online launcher app. This app enables users to remap keys, adjust key actuation points, assign multiple commands to a single key, enter game controller model.


more. If it cannot recognize your keyboard, please reach our support to get instruction.



B1 PRO ULTRA-SLIM WIRELESS KEYBOARD SPECIFICATIONS

- Number of keys: 77
 Battery: 800mAh
- 3. Battery life: 1200 hours
- 4. Charging time: Around 2.5 hours
- 5. Charging port: Type-C
- 6. Mode: 2.4GHz / Bluetooth / Wired
- 7. 2.4GHz / Bluetooth operating distance: Within 10 meters (open space)
- 8. Name of Bluetooth device: Keychron B1 Pro

B1 PRO ULTRA-SLIM WIRELESS KEYBOARD OVERVIEW



- 1) Bluetooth Channel
- (2) Caps Lock Indicator
- 3 2.4GHz / Bluetooth Indicator
- 4 Charging Indicator
- (5) BT Cable (Off) 2.4G (Mode Toggle Swtich)
- Mac Win
 (OS Toggle Switch)
- 7) Type-C Charging Port

LED STATUS OVERVIEW

LED Status

Power indicator Charging - Static red | Fully charged -

static green

Bluetooth / .4GHz Bluetooth / pairing -slow blinking | paired -static light indicator 2.4GHz and then off | Reconnecting -fast blinking

indicator Caps lock – light off

2.4GHZ / CABLE / BLUETOOTH MODE (MODE TOGGLE)

2.4GHZ MODE

- 1. Connect the 2.4GHz receiver to your device's USB Port.
- Switch the toggle to the 2.4GHz option. The keyboard will automatically connect to your device.

BLUETOOTH MODE

- 1. Switch the toggle to the Bluetooth option.
- 2. Hold "fn+1" key for 4 seconds to activate Bluetooth pairing (the Bluetooth indicator fast flashes for 3 minutes to detect pairing).
- 3. Search for the Bluetooth device "Keychron B1 Pro" on your device and connect it (the Bluetooth indicator goes off after successful pairing).

 Manualsum

Note: This keyboard supports pairing up to 3 devices simultaneously via key combination "fn" + "1" /

*The Bluetooth indicator will continue to flash for 3 minutes.

**Slow or failed connections may exist due to different Bluetooth versions, please make sure all the

settings are correct.

RECONNECT:

- 1. Switch the keyboard to the Bluetooth option to activate the keyboard.
- 2. The Bluetooth indicator flashes for 3 seconds and automatically pairs with the last paired device.
- 3. If the Bluetooth indicator is off, press any key to enter the reconnection mode again.
- * The keyboard must have been paired with the device to perform this function.

WIRED MODE:

- 1. Switch the toggle to the Cable option (it only works when a USB cable is plugged in).
- 2. Connect our cable with your PC and keyboard.

TROUBLESHOOTING

If unable to pair keyboard to device, confirm that the device you're trying to pair with is

Bluetooth-capable. If so, restart the device and try pairing it with the keyboard again.

^{*}Under Wired Mode, keyboard will not enter into Battery Saver Mode.