


年Y月M日	更正记事 ECN RECORD	版本REV
2024/08/14	首版发行	A
2024/11/22	加FCC ID	A1





10000mAh Power Bank

User Manual | VWS-F138


Introduction

The power bank is housed in a PC+ABS shell and is equipped with an LED digital display. It is powered by a rechargeable battery, providing versatile functionality and robust expansion capabilities. The three different-specified AC plugs are flexible enough to adapt to different power outlets worldwide. It supports both wired charging with built-in Lightning and USB-C cables and convenient 15W magnetic wireless charging, eliminating the need to carry extra cables when on the go.

Specifications

Model: FHX
Material: PC + ABS
Interface: USB-A/USB-C/Lightning/AC
Battery Capacity: 10000mAh (3.7V/37Wh)
Input (AC): 110-240V-50/60Hz (0.3A Max)
Input (USB-C): 5V=3A; 9V=2A; 12V=1.5A
Output (USB-A): 5V=3A
Output (USB-C): 5V=3A; 9V=2.2A; 10V=2.25A; 12V=1.67A
Output (Built-in USB-C Cable): 5V=3A; 9V=2.2A; 10V=2.25A; 12V=1.67A
Output (Built-in Lightning Cable): 5V=2.4A
Output (Wireless): 15W/10W/7.5W/5W


Product Overview





- ① Power Button
- ② AC Plug
- ③ USB-A Output
- ④ USB-C Input/Output
- ⑤ Built-in USB-C Output
- ⑥ Built-in Lightning Output
- ⑦ Magnetic Wireless Charging Output
- ⑧ EU Converter
- ⑨ UK Converter


Front

What's in the Box



 10000mAh Power Bank x1



 EU Converter x1



 UK Converter x1


 User Manual x1

For more interesting information and events, please follow us on social media platforms:


 Facebook


 LinkedIn


 Instagram

For warranty service or support, please contact Vention team:
 Website: www.ventiontech.com Email: vention@ventiontech.com

Instructions for Use

Charge the Power Bank

- Select the appropriate plug for the power bank, insert it into the socket, and start charging. (For the EU/UK converter, simply attach it without removing or replacing the original plug; For US/CN sockets, unfold the plug to fit accordingly and start charging.)
- Use an external cable to connect the USB-A port for charging the power bank.

Charge Your Devices

- Plug the built-in USB-C/Lightning cable into your phone or other device to begin charging.
- Place your magnetic wireless charging-compatible device near the wireless charging area of the power bank. It will automatically align and snap into the correct charging position to start charging.
- Use a suitable cable to connect your device to the USB-A port of the power bank for charging.

Notes

Do not use the product in humid, high temperature or outdoor conditions.
 Do not pour water into the product and use the water-immersed one.
 Do not disassemble the product.
 Do not use the product if damaged surface founded.
 Keep the in-use product out of reach of children to prevent accidents.
 Stop using the product immediately if there is significant heating.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

*RF warning for Portable device:
 The device has been evaluated to meet general RF exposure requirement.
 The device can be used in portable exposure condition without restriction.

FCC ID: 2A7Z4-FHX

Back

折叠尺寸: 70x90mm 展开尺寸: 210x90mm
 材质: 157g哑粉纸 3页风琴折 双面印刷
 蓝色印刷: C100 M:0 Y:0 K:0 参考: Pantone Process Cyan C

宁波福茂通讯科技有限公司 NINGBO FULMAN COMMUNICATION TECHNOLOGY CO.,LTD					
品名	FHX系列 多合一移动电源10000mAh			型号	VWS-F138
PART NAME	22.5W数显说明书			PART MODEL	
设计	Jacky	单位	mm	客户代码	
DESIGNER		UNIT		Client NO.	
校对		版本	A0	图号	
CHECK		REV		DWG.NO.	
核准		PAGE	1/1	更新	2024/11/22
APPR.		页数		UPDATE	