
User Manual



T20



Usage instructions

1, Power on/off: Press and hold the **dya** key to turn on, and press and hold the **dya** key to turn off.

2, Pause/play: touch and hold the **OPH** key to pause, touch the **OPH** key again to resume playback.

3, Previous/next song: long press the K≾ key to play the previous song, long press the K≯ key to play the next song.

4, mode selection: touch the ⋈ key for mode selection, each touch of the system will be in the radio, theBlue \tooth mode, AUX mode switch between

5, Radio mode: double click the the key to enter the system search mode, and then the system will automatically save the radio station after the search is finished.Press and hold the № key to select the next radio station, press and hold the KR key to select the previous radio station. Select the previous radio station (Tip: When using the radio function, please plug in the audio cable to do the sky(Tip: When using the radio function, please plug in the audio cable for the antenna, the reception effect will be better)

6, TWS interconnection mode: When the two stations are on, touch the K≰l key and hear the beep to enter TWS interconnection mode.

Power supply use instructions

Speaker built-in rechargeable cycle of 14500 cylindrical battery, when the power is low speaker will voice prompt low battery, please promptly plug in the charging cable, connect the 5V 1A charger to the deviceThe device is charged. When charging, the indicator lights up red, and when charging is complete, the red light goes out.

Caution

1, please store or use this product in a normal environment, not in the fire or overheating environment

- 2, Please do not put this product into any liquid has been any
- liquid spilled on this product

3, please use the charger with the rated input voltage required for this product to charge (Note that it should not exceed 5V 2A)

Warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: --Reorient or relocate the receiving antenna.


-- Increase the separation between the equipment and receiver --Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

 Consult the dealer or an experienced radio/TV technician for help NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

RF exposure:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Product parameters



Product List



Mainframe Instructions Audio cable TEPY-C

Warranty Card

Name:	
Tel:	
Add:	
Question:	
	Made in C