

Buddi Technical and User Publications
Device Installation Guide

Mini +

Publication release date 09/2024 v.1.0_1.0

+1 844-283-3487
+44 800-978-8800

sales@buddi.us
sales@buddi.co.uk

www.buddi.us
www.buddi.uk

COMMERCIAL IN CONFIDENCE

© buddi Ltd 2024



Mini +



Introduction

Use this Guide to assist with set-up and operation of Mini +. Mini + is a non-fitted solution which is charged using a micro USB.

Mini + alerts can action notifications to the Eagle Portal monitoring software system which is indicated by vibration feedback within the Mini + to the device wearer.



Equipment



1 Buddi Mini +



2 Micro USB
Charger Cable



3 Regional USB
Power Adapter*


** The USB power adapter has attachments suitable for regional applications*



Set-up Mini +

Make sure Mini + is ready for operation; charged and tested for communication response before instalment.

!Info The Mini + device will automatically wake from stand-by when it is connected to a power source




A Mini + actions and alerts – panic mode

- To activate a panic alert long press the Mini + button and hold for at least 3 seconds
- To deactivate panic mode a short time is allocated for the wearer to press the Mini + button again which will cancel the device panic mode status
- Mini + will send an alert to the Eagle Portal monitoring system when panic mode is active

Button Action	LED	VIBRATE	Mini+ State Indication
Press and hold to see the LED indication (long press)	BLUE (flashing)	Yes	Mini + panic mode activation
Press momentarily to see the LED indication (short press)	GREEN (flash)	Yes	Mini + panic mode deactivation
-	BLUE (blink)	-	Mini + has activated panic mode and cannot be deactivated

Charge Mini +



B Charge Mini +

- Plug the micro USB cable into the Mini + charging port - connect the USB power charger to a mains socket
- Mini + will display an LED indication on the front panel to indicate when the device is fully charged

LED	Mini+ State Indication
AMBER	Mini + is low power Charge Mini +
GREEN (solid for 5 seconds)	Mini + is connected to the USB charge cable successfully
GREEN (Blinking)	The Mini+ is charging
GREEN (solid continuous)	Mini+ is fully charged

Info 2 hours is the approximate time required to fully charge the Mini + (0% to 100%)



Regulatory Information

FCC Warning

EN

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.